Sanitation Tracker Date **Steps** 1: Wear PPE 2: Rinse lines out with water 3: Pressurize lines for leaks 4: Send scrubbing ball through circuit loop 5: Place proper valve, to control the flow of Caustic cleaner in the hot water tank 6: Open valve to slowly release the 1 to 2 percent of the chemical in to the water tank when the water has reached a temperature of 150 to 160 degrees Fahrenheit. 7: Allow this solution mixture circulate for the allotted time of П 8: Rinse out entire lines out with water 9: Send Scrubbing ball through one last time after rinse. 10: All materials used placed at or in proper receptacles when finished

Sanitation Tracker Date Steps

Sanitation Tracker Date Steps D D D D